


PARTS LIST

DEMOLITION HAMMER

BDH4700

Art# 020608



Use only BORMANN genuine parts as specified in the parts list for repair or replacement.
Check if your machine meets the applicable models listed below.
The contents described in the parts list may change due to improvement.



APPLICABLE:

March 2020



BDH4700 Fig. A



No#	Code	Description (EN)	QTY	Notes
1	0206080001	Pin 4*32	1	
2	0206080002	Washer 32*17*2	1	
3	0206080003	Lock rod Spring	1	
4	0206080004	Lock rod cover	1	
5	0206080005	O-Ring 18*8	2	
6	0206080006	Iron Head	1	
7	0206080007	Lock rod	1	
8	0206080008	Inner hexagon screw M12*75	4	
9	0206080009	Flat Washer 12	4	
10	0206080010	Iron Head Spring	4	
11	0206080011	O-Ring 65*3.2	1	
12	0206080012	Ram Hammer cover	1	
13	0206080013	O-Ring $\phi 33 \times \phi 3.5$	2	
14	0206080014	Impact hammer rod	1	
15	0206080015	Hammer Washer	1	
16	0206080016	Damping Washer	1	
17	0206080017	Locating seat	1	
18	0206080018	Cylinder case	1	
19	0206080019	Inner hexagon screw M10*50	4	
20	0206080020	Spring Washer 10	4	
21	0206080021	Flat Washer 10	4	
22	0206080022	O-Ring 97*3	1	
23	0206080023	Cylinder	1	
24	0206080024	Damping Washer	1	
25	0206080025	Cylinder Set	1	
26	0206080026	Hammer	1	
27	0206080027	O-Ring 48*5.3	2	
28	0206080028	Piston	1	
29	0206080029	Piston Pin	1	
30	0206080030	Connecting rod	1	
31	0206080031	Needle bearing HK162216	1	
32	0206080032	Gear Box	1	
33	0206080033	Needle cover	1	
34	0206080034	Ring 40	1	
35	0206080035	Needle bearing RNA4904	1	
36	0206080036	Pin 4*4*12	1	
37	0206080037	Crank shaft	1	
38	0206080038	Stator House	1	
39	0206080039	O-Ring 56*3	1	
40	0206080040	Oil Seal	1	
41	0206080041	Stator	1	
42	0206080042	Wool Washer	1	
43	0206080043	Spring Washer 5	8	
44	0206080044	Self-tapping screw ST4.8*55	2	
45	0206080045	Rotor	1	
46	0206080046	Self-tapping screw ST4.2*14	7	
47	0206080047	Power spring	2	
48	0206080048	Brush	2	
49	0206080049	Brush Holder	2	
50	0206080050	Rotor set	1	
51	0206080051	Inner hexagon screw M5*30	2	
52	0206080052	Bearing Holder	1	
53	0206080053	Bearing 6201	1	
54	0206080054	Bearing Board	1	
55	0206080055	Adjust Washer	1	

No#	Code	Description (EN)	QTY	Notes
56	0206080056	Fan Guide	1	
57	0206080057	Gex Nut M12*1.25	1	
58	0206080058	Buttom	1	
59	0206080059	Flat Washer	6	
60	0206080060	Inner hexagon screw M5*22	4	
61	0206080061	Inner hexagon screw M5*35	2	
62	0206080062	Oil Seal 20*35*8	1	
63	0206080063	Neddle Bearing F-225538-1	1	
64	0206080064	Brush Cover	1	
65	0206080065	He Nut M8	4	
66	0206080066	Handle Set	1	
67	0206080067	Flat Washer 8	4	
68	0206080068	Damper spring $\Phi 1.5$	2	
69	0206080069	Damper Board	2	
70	0206080070	Damper screw	4	
71	0206080071	Damper holder	2	
72	0206080072	Left Handle	1	
73	0206080073	Inductance	1	
74	0206080074	Capacitance	1	
75	0206080075	Switch	1	
76	0206080076	Right Hnadle	1	
77	0206080077	Self-tapping screw ST3.9*18	5	
78	0206080078	Cable Board	1	
79	0206080079	Self-tapping screw ST3.9*16	2	
80	0206080080	Cable cover	1	
81	0206080081	Cable	1	
82	0206080082	Self-tapping screw ST4.8*18	2	
83	0206080083	Flat Washer	12	
84	0206080084	Inner hexagon screw M6*16	6	
85	0206080085	Damper Spring $\Phi 2$	2	
86	0206080086	Insulating bush	1	
87	0206080087	Bear 6202	2	
88	0206080088	Duplicate gear	1	
89	0206080089	Gear cover	1	
90	0206080090	Inner hexagon screw M6*22	6	
91	0206080091	Spring Washer 6	6	
92	0206080092	Ring 20	1	
93	0206080093	Big Gear	1	
94	0206080094	Ring 47	1	
95	0206080095	Bearing 6204	1	
96	0206080096	Oil Cover	1	
97	0206080097	O-Ring 31.5*2	1	
98	0206080098	Hoop	1	
99	0206080099	Hoop seat	2	
100	0206080100	Knob Cover	1	
101	0206080101	Nut M8	1	
102	0206080102	Knob	1	
103	0206080103	Auxiliary Handle	1	
104	0206080104	Inner hexagon screw M8X130	1	
201	0206080201	O-ring assy	1	
202	0206080202	Brush holder assy	1	
203	0206080203	Rear handle assy	1	
204	0206080204	Oil cover assy	1	
205	0206080205	Gear assy	1	
206	0206080206	Front handle assy	1	
207	0206080207	Pin assy	1	